

# Hardwood Floor Cleaning and Preservation System

Hardwood Übors are gaining in popularity. Millions of square feet are installed each year. In many homes, carpet is out and hardwood is in. Professional cleaners may now take advantage of a simple, safe, cleaning and preservation system designed to prolong the life and restore the shine to hardwood. Increased income, higher proû and satisûed customers will be the result for the professional who embraces this system.

## Before You Begin

## LEARN FROM THE PROS

It's easy to become proûcient and successful using the Hydro-Force Hardwood Floor Cleaning and Preservation System. It only takes 15 minutes to watch the DVD which will take you through a step by step process. Once you have the basics, and get the equipment and products, you are ready to go to work.



# 1 Clean & Prep

- · Vacuum or dust mop the Übor to remove all soil. Do not use a treated dust mop.
- · Mix one part Heavy Duty Hardwood Cleaner with 4 parts warm water in the cleaning machine.
- With the solution pumping, the brush rotating and the vacuum turned on, begin moving the machine forward at a moderate speed. Reverse on the same line at the same speed. Continue into the next area with the same procedure. Wipe up any remaining solution with an absorbent Lat mop.
- Mix one part Wood Fresh™ Hardwood Cleaner with 4 parts warm water in the cleaning machine.
- Proceed to clean and neutralize the complete Übor in the same manner as explained above.

· With customer approval, choose Gloss or Satin Finish.

Apply Preservation

- The Unish may be applied with a Uat mop using either a clean cotton terry cloth cover or a  $micro\hat{U}$ ber cover. 30 minutes prior to applying the Ûhish, the container should be gently rocked to mix the ingredients.
- Start in the furthest area from your exit. Apply a small amount of Ûhish in a 4 or 5 foot area, spreading it thinly and uniformly as you work your way back toward the exit door.
- · If a second coat is desired, allow one hour before applying.







# **Helpful Hints**

- TrafÚc: Allow one hour dry time before allowing stocking feet onto the Ûhish. Allow 24 hours before shoe traft and replacing furniture. Allow 48 hours before replacing rugs. Remember that it is a great time to take oriental rugs off site to clean them, returning them within a week. We suggest you offer vour customer shoe covers to wear over their shoes for the next couple of days.
- · Pregualify: The pre-inspection and prequaliûcation step is essential for the success of each job. The system emphasizes the importance of preserving the original Ûnish, so hopefully the customer will never have to go through the messy process of sanding and recoating their hardwood. This system does not make damaged or heavily scratched Übors look like new. That
- does not mean the customer will not be thrilled with the results, but to give that thrill to the customer, realistic expectations need to be established. We suggest you under promise and then over perform.
- · Important Step: The cleaning and preparation steps are important. The two cleaners both clean and treat the Übor to make it more receptive to the Preservation Finish. The Uhish should be applied within one hour of cleaning, otherwise the Ûnish will not bond well.
- Cleaning Only: Hardwood Übors are generally dirty - much dirtier than most customers realize. This gives the professional an option for cleaning only. Using the two part cleaning system with a quality machine will make a big difference in

- the look of a soiled Übor. If cleaning is performed without the preservation Ûnished being applied, avoid shoe trafûc for two hours following the cleaning.
- · The Finish: The Gloss and Satin Finish are both high quality Ûhishes. The customer should be aware that the gloss Unish will show slightly more imperfections such as scuffs and micro scratches as it wears. Most Unishes from the factory and those applied to new raw wood will have a satin Ûhish. In any case the customer will decide.
- The Price: Prices generally range from \$.75 to \$1.50 depending on the size of the job. This price excludes jobs that require a lot of repairs or preparation. Depending on the extra work, this could raise the charge to the \$1.50 to \$3.00 per foot range.

