

CEP 6502GU/GTL, 6503GU/GTL 99577, 99577C

Temporary branch power distribution unit
with Ground Fault Protection for personnel

Installation and Operating Instructions

SPECIFICATION

These installation and operation instructions apply to the following temporary power branch distribution system components. Do not discard these instructions, save for future Reference.

PORTABLE POWER DISTRIBUTION UNITS

These units are rated either 20 or 30 amps, 125/250 VAC, Single Phase. The max. ampacity for the 20 amp unit is 40A @ 120V, and the 30 amp unit is 40A @ 120V. The 20 amp, 120 volt outlets are individually protected by circuit breakers and GFCI circuit modules.

Model Number(s)	20 Amp Receptacle
6502GU,6503GU 99577,99577C	U-Ground
6502GTL, 6503GTL	Twist Lock

INTRODUCTION

CEP temporary power distribution units equipped with GFCI modules that will protect you from electrocution hazards resulting from ground faults. Ground faults are current leaks and can result in electric shock. Currents of only 60/1000 of an ampere can be fatal. The GFCI protection provided by CEP temporary power distribution units significantly minimizes shock hazards. CEP temporary power distribution units,

which are UL listed as Class A, Group I interrupters, respond to fault currents as low as 3-6 mill amperes, and will shut of the current within 1/40th of a second. The temporary power distribution unit is designed to provide protection against electrical shock hazards due to line-to-ground faults. Although the GFCI module does not eliminate the hazard of a shock, it does limit the duration of the shock to a period considered safe for normally healthy persons.

GFCI modules will provide protection against ground faults only. They will not protect against overloads or short circuits. There is no known device that will guard against the electrical shock hazard resulting from contact with both the "hot" and neutral wires of the electrical circuit.

**ELECTRICITY IS DANGEROUS.
EVEN WHEN SAFETY DEVICES ARE
PRESENT, HANDLE WITH CARE AND USE
REASONABLE CAUTION.**

LET CAUTION PREVAIL

The CEP temporary power distribution unit is designed to be used on a grounded electrical supply system. It will not operate when supplied from a power source which is not grounded. Over-current protection of the proper rating, according to the National Electric Code, Article 240, must be used on the supply circuit feeding the temporary power distribution units.



TEST PROCEDURE

All Models

Connect the temporary power distribution unit to an appropriate power source.

1. Verify all circuit breakers are in the “on” position.
2. Push the test button on the individual GFCI module. The unit should trip.
3. Push the reset button. The indicator light should come on.
4. Repeat steps 2 & 3 for the remaining module.

TROUBLE SHOOTING

The GFCI Modules within the temporary power distribution unit will trip whenever one or more of the following abnormal conditions exist in the line (supply) side circuit:

1. Either line (hot) conductor is transposed with the neutral conductor.
2. Either line (hot) conductor is open (disconnected)
3. There is an excessive voltage imbalance between line 1 and line 2 circuits. This may be the result of an open neutral conductor in the supply circuit.

When the abnormal condition(s) in the supply circuit is corrected, the unit may be reset for normal use by completely removing and then reapplying line power. It is recommended that the GFCI test procedure be repeated at this time. When a GFCI module trips, attempt to reset it by pressing the reset switch, being careful to look for possible danger to personnel. If the module resets, the fault was momentary and has cleared. If it trips again immediately, the fault is still present and the GFCI module is performing its safety function. To locate the fault, disconnect all loads and again try pressing the reset switch. The module should reset. Reconnect the loads one at a time. The module will trip when the faulted load is reconnected. Inspect all tools, appliances and extension cords in the faulted load circuit, repairing or replacing any that are not in good condition.

NOTE: Tripping of a circuit breaker in these models can only result from an overload or short circuit condition in its individual load circuit. When the fault in the load circuit is corrected or removed, the circuit breaker can be reset for normal use by switching handles to “OFF” position and then to the “ON” position.

NUISANCE TRIPPING

All cables have some capacitive leakage. In a 120 volt system, there is a limited to the length of cable which can be run before sufficient leakage to ground will build up causing a GFCI to trip. Individual 120 volt branch circuit load cords should be limited to 250 feet in length.

APPLICATION NOTES

Enclosure is a NEMA Type 1, constructed for indoor use to provide a degree of protection to personnel against access to hazardous parts and to provide a degree of protection of the equipment inside the enclosure against ingress of solid foreign objects (falling dirt).

HIGH VOLTAGE LIGHT

An illuminated high voltage light indicates the input wiring is incorrect; check the power source.

CONTACT MONITOR LIGHT

The red monitor light is a welded contact indicator. If the monitor light is on with the unit tripped, it indicates the contact is welded, and the unit should be replaced immediately -- there is no GFCI protection. When the TEST button is pressed, both the POWER light and MONITOR light should go out, and come back on when the RESET button is pressed.

MAINTENANCE & REPAIR

CAUTION: Electrical power supply **MUST BE OFF AND DISCONNECTED** before and during any repair or maintenance. Repair and maintenance must be performed by a trained and competent electrician.

WARNING: If any parts or components of this temporary distribution box appear to be missing, broken or show signs of damage, **DISCONTINUE USE IMMEDIATELY!** Do not modify these devices in any way. Replace worn or damaged components. Failure to do so could cause serious personal injury or death.

6502GU/GTL, 6503GU/GTL, 99577, 99577C REPLACEMENT PARTS	
DESCRIPTION	PART #
20 AMP 125V U-GROUND DUPLEX RECEPTACLE	RECDUP
20 AMP 125V TWIST LOCK RECEPTACLE*	205R
20A 125V BOLT ON BREAKER	CB120NB
20A GFCI PANEL MOUNT MODULE	GF6095
20A 125/250V TWIST LOCK PLUG**	2014P
30A 125/250V TWIST LOCK PLUG***	3014P
50A 125/250V TWIST LOCK PLUG****	6365M

*6502GTL AND 6503GTL

** 6502GU/GTL

*** 6503GU/GTL

**** 99577 AND 99577C

