

1. Provide Advanced Peroxide Cleaner enough time to work its way into the substrate and lift inanimate contaminants out through the foaming action. The dwell time will depend on the thickness and porosity of the substrate but is usually 5 to 10 minutes.
2. After a layer of foam has developed agitation will assist in removing more debris. Use a stiff nylon bristle brush to fully agitate the surface.
3. As Advanced Peroxide Cleaner dwells on the surface it will continue to lift debris and remove staining.
4. A second application of Advanced Peroxide Cleaner may be necessary in order to achieve the desired results.
5. Before Advanced Peroxide Cleaner dries the surface should be thoroughly wiped clean. The full brightening effects will be seen within 24 hours as the surface dries. After cleaning, disinfect with ShockWave or ShockWave RTU.

**Coverage:** 500 ft<sup>2</sup> per gallon on porous surfaces and up to 1200 ft<sup>2</sup> per gallon on non-porous surfaces. Note that coverage rates are approximate and depend on how heavily the Advanced Peroxide Cleaner is applied to the substrate.

**Storage:** Store in a dry place at temperatures between 40°F (4.5°C) and 90°F (32°C). Store securely closed and upright in original container. Vented cap can leak if container is placed on side. Do not store in direct sunlight as this will reduce the potency of the product. Avoid shipping or storing below freezing or above 90°F.

**Disposal:** Store in a well-ventilated place. Keep container tightly closed. Store in a locked area inaccessible to children.

**Contains:** Water (7732-18-5), Hydrogen Peroxide (7722-84-1), Primary Alcohol Ethoxylate C9 (68459-46-3), Sodium Octane Sulfonate (524-84-5), Proprietary Chelating Agent (N/A).

**CAUTION! KEEP OUT OF REACH OF CHILDREN. FOR PROFESSIONAL USE ONLY. 24 hour Emergency "CHEM-TEL" - 1-800-255-3924**

Always take care to avoid skin and eye contact by using protective measures such as nitrile rubber gloves (or equivalent) and safety glasses. Do not take internally. Close container after each use. Keep from freezing. Do not return unused product to the original container.

**WARNING:** Cancer and Reproductive Harm - www.P65Warnings.ca.gov

For Technical Information call 800.342.3755

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of this product are beyond our control. Neither ICP Construction, Inc., nor its agents shall be responsible for the use of this product or any procedures or apparatus mentioned. We recommend that the prospective user determine the suitability of this product, for each specific project and for the health and safety of personnel working in the area.

For additional information check Safety Data Sheet or Product Data Sheet available online at [www.fiberlock.com](http://www.fiberlock.com).

IAQ, the IAQ Logo and other marks in this literature are trademarks of ICP Construction, Inc.



H315 - Causes skin irritation.  
H315 - Provoque une irritation cutanée.  
H319 - Causes serious eye irritation.  
H319 - Provoque une sévère irritation des yeux.  
H335 - May cause respiratory irritation.  
H335 - Peut irriter les voies respiratoires.

Use only outdoors or in a well-ventilated area; Avoid breathing mist/vapours/spray; Wear protective gloves/protective clothing/eye protection/face protection; See SDS for full list of P phrases

Utiliser seulement en plein air ou dans un endroit bien ventilé; Éviter de respirer les brouillards/vapeurs/aérosols; Porter des gants de protection/des vêtements de protection/un équipement de protection des yeux/du visage; Voir SDS pour la liste complète des phrases P

Specific treatment (see advice on this label): Take off contaminated clothing and wash before reuse.; IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.; Call a POISON CENTER or doctor/physician if you feel unwell.; If eye irritation persists: Get medical advice/attention.; IF ON SKIN: Wash with plenty of soap and water.; See SDS for full list of P phrases

Traitement spécifique (voir les conseils sur cette étiquette): Enlever les vêtements contaminés et les laver avant réutilisation; EN CAS DE CONTACT AVEC LES YEUX: rincer avec précaution à l'eau pendant plusieurs minutes. Enlever les lentilles de contact si la victime en porte et si elles peuvent être facilement enlevées. Continuer à rincer; Appeler un CENTRE ANTIPOISON ou un médecin en cas de malaise; Si l'irritation oculaire persiste: consulter un médecin; EN CAS DE CONTACT AVEC LA PEAU: laver abondamment à l'eau et au savon; Voir SDS pour la liste complète des phrases P

**Canadian Contact Info:**  
4050-B Shaderview Crescent Suite 200  
Mississauga, ON L5L 5Y5 Canada

BLEACH FREE WHITENING FORMULA

# IAQ

## ADVANCED PEROXIDE CLEANER

Bleach Free Stain Remover and Cleaner

- Bleach Free Stain Remover
- Superior Lifting Action
- Whitens and Removes Staining
- Advanced Product Chemistry

NET CONTENTS: 1 Gallon

For Professional Use Only



ADVANCED PEROXIDE CLEANER

# 8314-1