

Temperature & Humidity Meter, Compact Series

Introduction

This compact thermo-hygrometer measures temperature and relative humidity. The R1910 features Data Hold and Min/Max functions and is designed for one-handed operation.

⚠ Warning:

Before using product, please read the operation manual carefully.

Operation Safety

- 1. Check the meter before using to ensure the instrument is not damaged.
- 2. Do not open the meter.
- 4. Remove the batteries if the instrument will not be used for an extended period of time.
- Do not use the meter in high temperature, humidity, flammable, combustible or strong electromagnetic environments.
- Use a soft cloth and neutral detergent to clean the instrument. Do not use strong agents or solvents.

Note: Keep thumb away from sensor when taking readings as body temperature may affect readings.

Display Description

- 1. Max
- 2. Min
- Data Hold
- 4. Low Battery Indicator
- 5. Relative Humidity
- 6. °C
- 7. °F
- 8. Temp. Value
- 9. Humidity Value



Key Functions & Setup

ON/OFF

Press once to turn on unit. Press again to power off. Disable the product's auto power off feature by pressing and holding HOLD and then press the ON/OFF key to enable/ disable auto power off, LCD will display "APO OFF" to indicate status.

°C/°F

Press this button to switch between Celsius and Fahrenheit.

MAX/MIN

Press this button to cycle through maximum, minimum and live measurement functions. Select maximum and the maximum reading will be shown; select minimum and the minimum reading will be shown.

HOLD/BL

Specifications Temp. Measuring Range: 14 to 140°F (-10 to 60°C)

Temp. Accuracy: ±2.0°F (1.0°C) **Humidity Measuring Range:** 0 to 100% RH Humidity Accuracy: ±5% RH **Humidity Resolution:** 0.1% RH Display: **Dual LCD** Backlit Display: Yes Data Hold: Yes Maximum: Yes Minimum: Yes

Sampling Rate: 1 time/second

Overange Indicator: Yes

Auto Shut-Off: Yes (after 5 minutes, off)
Low Battery Indicator: Yes

Power Supply: 3 "AAA" batteries

Product Certifications: CE

Storage Temperature: 14 to 140°F (-10 to 60°C)

 Operating Humidity Range:
 10 to 80%


 Dimensions:
 6.3 x 2 x 1.1"

 (155 x 50 x 28mm)

 Weight:
 4.20z (102g)

Battery Installation and Replacement

- This meter uses 3 AAA batteries. Refer to the figure below for battery installation and replacement steps.
- 2. Push the battery cover open in the direction of the arrow, lift the cover and remove the batteries.
- 3. Install new batteries in accordance of polarity indications.
- 4. Close the cover tightly after installing new batteries.



REED Instruments

1-877-849-2127 | info@reedinstruments.com | www.reedinstruments.com